

MILLIKEN RESEARCH CORPORATION

Spartanburg, South Carolina

LABORATORY NOTEBOOK

Name *Chris Kochanowicz* Book No. 10120

Used from *June 11, 1996* To *April 11, 2000*

Laboratory Book Nº 10120
Date Received: 6-11-96
Assigned To. Chris Kochanowicz
Returned To: _____
Date Returned: _____

This book is the property of Milliken Research Corporation. The Assignee is responsible for its return to the permanent records of Milliken Research Corporation.

**NOTEBOOKS ARE NOT TO BE TAKEN OUTSIDE OF THE COMPANY
OR CORPORATION PREMISES WITHOUT THE PERMISSION OF
DIRECTOR OF RESEARCH.**

The procedure outlined below is required for one purpose primarily---to make the notebook acceptable as indisputable legal proof in patent proceedings of what was done, and exactly when it was done. The exact date on which a given idea was first in mind has often been the basis for awarding valuable patents. Therefore, as soon as you have any idea, even though it may seem trivial or obvious to you, you will, under the procedure outlined, put it in your notebook with complete details. This will apply whether it is a small modification in experimental procedure or apparatus design which may give improved yields or operation, or what may be a major improvement or innovation in products or processes.
GET IT DOWN.

The early date of record may mean the difference between getting an important patent for the Research Corporation in your name, or losing it to some other company which can actually keep our stockholder mills from using the idea.

If after further thought and discussion, or a few experiments, you decide that the idea may have value, you may draw up a formal description, either as a memo or on the invention record form provided, for submission to the Patent Division.

It is a function of the Patent Division to review the yellow sheets in this notebook as forwarded by you and to cull from them all ideas having patentable novelty, but the invention record form submitted in this way will serve to accent those ideas considered by you to be most important.

<u>163.34</u> <u>g</u>	1) $13.87 \Rightarrow 7.83\% \text{ }^{10.1}$	4.62%
<u>136.96</u> <u>g</u>	2) $13.79 \Rightarrow 14.48\% \text{ }^{20.1}$	9.22
<u>300</u> <u>g</u>	3) $13.75 \Rightarrow 20.22\% \text{ }^{20.2}$	13.80
	4) $13.76 \Rightarrow 25.25\% \text{ }^{(4.62\%)}$	8.39
	5) $14.23 \Rightarrow 29.82\% \text{ }^{50.7}$	23.13
	6) $13.71 \Rightarrow 33.72\% \text{ }^{60.7}$	60.7
	7) $\frac{13.70}{96.81} \Rightarrow 37.21\% \text{ }^{70.7\%}$	70.7%
<u>110.79</u>	8) $13.68 \Rightarrow 40.35\% \text{ }^{80.7\%}$	80.7%
	9) $13.93 \Rightarrow 43.24 \text{ }^{90.8\%}$	90.8%
Purple 300 B 42% R 58%	10) $12.54 \Rightarrow$	<u>140%</u>

Burgundy 410 B 23% 360385
 R 62% 386
 Y 15% 387

Harriet	6	127.17
Tusong	6	12.49
Brenda	5	
Mary	5	
Daniel	7	

INDEX

EQUIPMENT - UNLESS OTHERWISE NOTED, THE FOLLOWING EQUIPMENT IS USED

BALANCE

SARTORIUS BASIC ID# 00190

SARTORIUS ANALYTIC ID# 00084

AMERICAN CONSTANT TEMPERATURE OVEN ID# 00086

SARTORIUS BASIC ID# 00077

INDEX

TABLE OF CONTENTS

SEE LOTUS NOTES - LABORATORY NOTEBOOKS DATABASE

EVALUATION OF STRASTINT 53-P DISPENSER

OBJECTIVE : EVALUATE THE STRASTINT 53-P DISPENSER AS A CANDIDATE FOR A MANUAL REACTANT DELIVERY SYSTEM.
 DEFINE THE ACCURACY OF THIS DISPENSER WITH ORANGE X96 (WHICH IS OUR HIGHEST VISCOSITY REACTANT PRIMARY)

THE STRASTINT 53-P IS SUPPLIED BY FLUID MANAGEMENT

THE EQUATION FOR SPECIFIC GRAVITY VS. TEMPERATURE FOR ORANGE X96 WAS DERIVED SEE 9949-74

$$\text{ORANGE X96} : Y = -0.000682 X + 1.1460$$

MULTIPLE SHOTS WILL BE DONE AT DIFFERENT SETTINGS ON THE STRASTINT.

1ST SETTING - 5.0 ml - SHOTS WEIGHED INTO A TARED DISPOSABLE BEAKER

5.5 g	5.5 g	5.6 g	5.6
11.1 g	5.6	11.1	5.5
16.7 g	5.6	16.8	5.7
22.2 g	5.5	22.3	5.5
27.8 g	5.6	27.9	5.6
33.4 g	5.6	33.5	5.6
38.9	5.5	39.1	5.6
44.5	5.6	44.7	5.6
50.1	5.6	50.3	5.6
55.7	5.6	55.8	5.5

PRODUCT TEMP. 24.8°C

Date 11 June 1996

Date June 13 1996

Signature

Witness

EVALUATION OF STRASTINT 57-P DISPENSER

20 DATA SAMPLES PLUGGED INTO SAC PACK/PLUS

@ 5.0 ml DISPENSE SETTING (20 SHOTS)MEAN 5.57 gCONTROL LIMITS (3 σ TABULAR) UPPER 5.74 g
LOWER 5.41 gTARGET WEIGHT: $Y = -0.000682(24.8) + 1.1460$

$$Y = 1.1291 \Rightarrow \text{SPECIFIC GRAVITY}$$

$$(5.0)(1.1291) = \underline{\underline{5.65 g}}$$

NEW SETTING 0.5 ml - SHOTS WEIGHED INTO TARED DISPOSABLE BEAKER
PRODUCT TEMP. 24.0 °C

0.6 g	{	0.6	6.1 g	}	0.6
1.1 g		0.5	6.6		0.5
1.6 g		0.5	7.2		0.6
2.2 g		0.6	7.7		0.5
2.8 g		0.6	8.3		0.6
3.3 g		0.5	8.8		0.5
3.8 g		0.5	9.4		0.6
4.4 g		0.6	9.9		0.5
5.0 g		0.6	10.5		0.6
5.5 g		0.5	11.0		0.5

@ 0.5 ml DISPENSE SETTING (20 SHOTS)MEAN 1 0.55 gCONTROL LIMITS (3 σ TABULAR): UPPER 0.76 g LOWER 0.34 gTARGET WEIGHT: 0.56 g

Date 11 June 1996

Date 13/1996

Signature

Chris Kostanowicz

Witness

Jill Stoler

EVALUATION OF STRASTINT 58-P DISPENSER

NEW SETTING 17.0 ml - SHOTS WEIGHED INTO A TARED DISPOSABLE BEAKER
 PRODUCT TEMP. 23.0°C


19.0g	19.0g	19.0g	19.0	18.9g	18.9g	18.9g	18.9
38.0	19.0	38.0	19.0	37.9	19.0	37.9	19.0
56.9	18.9	57.0	19.0	56.9	19.0	57.0	19.0
75.9	19.0	76.0	19.0	75.9	19.0	76.0	19.0
94.9	19.0	95.0	19.0	94.8	18.9	95.0	18.9
113.9	19.0	113.9	18.9	113.8	19.0	113.9	19.0

② 17.0 ml DISPENSE SETTING (20 SHOTS)

MEAN: ~~18.86g~~ ^{CTK} 18.97g

CONTROL LIMITS (3σ TABULAR): UPPER 19.09g LOWER 18.86g

TARGET WEIGHT: 19.22g



Date 11 June 1996
 Date June 13, 1996

Signature Chris Kochanowski
 Witness John H. Hale

EVALUATION OF STRASTINT 53-P DISPENSER AT ROOM TEMPERATURE

ORANGE X96 LOT# RD232

PRODUCT TEMPERATURE 25.0°C

OBJECTIVE: PLOT CURVE OF GRAMS DISPENSED VS. DISPENSER SETTING TO DERIVE THE CURVE EQUATION. TEST EQUATION AT VARIOUS TARGET AMOUNTS.

<u>DISPENSER SETTING</u>	<u>WEIGHT GRAMS</u>
1.0	1.08
10.0	12.26
20.0	22.33
30.0	33.25
40.0	44.72
50.0	55.83
60.0	66.97
70.0	78.08
80.0	89.15
90.0	100.46
100.0	111.56
110.0	122.76
120.0	133.93
130.0	145.07
140.0	156.16

A PLOT OF DISPENSER SETTING VS. WEIGHT YIELDED THE FOLLOWING RESULTS:

$$R^2 = 0.99996$$

$$Y = 0.89792X - 0.18779$$

Date 12 June 1996
Date June 13, 1996


Signature

Witness

EVALUATION OF STRASTINT 53P DISPENSER AT ROOM TEMPERATUREORANGE X96 EQUATION AT 25.0°C $Y = 0.89792X - 0.18779$

<u>TARGET WEIGHT</u>	<u>EQUATION RESULT</u>	<u>DISPENSER SETTING</u>	<u>ACTUAL WT DISPENSED</u>	<u>% ERROR</u>
20.0 g	17.8	18.0	19.90 g	-0.5%
50.0 g	44.7	45.0	50.43 g	0.9%
75.0 g	67.2	67.0	74.98 g	-0.03%
90.0 g	80.6	80.5	90.05 g	0.067%
115.0 g	103.1	103.0	115.16 g	0.17%
140.0 g	125.5	125.5	140.34 g	0.2%
350.0 g	314.1	157.0 x 2	350.95 g	0.3%

Strastint 53P Dispenser (25C)



EVALUATION OF STRASTINT 53-P DISPENSER AT 14°C

THE STRASTINT 53P WAS PLACED IN A TEMP. CONTROLLED ROOM AND TEMP SET AT 55°F. REACTANT ORANGE X76 WAS ALLOWED TO ADJUST TO TEMP OVER NIGHT.

PRODUCT TEMP. 14°C

<u>STRASTINT SETTING</u>	<u>WEIGHT GRAMS</u>
1.0	1.09
10.0	11.22
20.0	22.43
30.0	33.79
40.0	44.98
50.0	56.21
60.0	67.50
70.0	78.64
80.0	89.68
90.0	100.97
100.0	112.41
110.0	123.39
120.0	134.94
130.0	145.98
140.0	157.21

A PLOT OF DISPENSER SETTING VS. WEIGHT YIELDED THE FOLLOWING RESULTS :

$$R^2 = 0.99999$$

$$Y = 0.89052X - 0.01420$$


Date 13 June 1996
June 13, 1996

Signature

Witness

EVALUATION OF STRASTINT 53P DISPENSER AT 14°CORANGE X96 EQUATION AT 25°C $Y = 0.89052X - 0.01420$

<u>TARGET WEIGHT</u>	<u>EQUATION RESULT</u>	<u>DISPENSER SETTING</u>	<u>ACTUAL WT DISPENSED (g)</u>	<u>% ERROR</u>
20.0g	17.8	18.0	20.16 g	0.8%
50.0g	44.5	44.5 (45.0)	50.09 (50.60)	0.2% (1.2%)
75.0g	66.8	67.0	75.16	0.2%
90.0g	80.1	80.5	90.45	0.5%
115.0g	102.4	102.5 (103.0)	115.12 (115.68)	0.1% (0.6%)
140.0g	124.7	125.0 (125.5)	140.35 (141.04)	0.2% (0.7%)
350.0g	311.7	2x156.0 (2x157.0)	350.23 (352.34)	0.1% (0.7%)



Date June 13, 1996

STRASTINT 53P TEMPERATURE COMPARISON

25°C EQUATION: $Y = 0.897792X - 0.18779$

14°C EQUATION: $Y = 0.89052X - 0.01420$

<u>DISPENSER SETTING</u>	<u>25°C</u>	<u>14°C</u>
1.0	1.08g	1.09g
10.0	12.26	11.22
20.0	22.33	22.43
30.0	33.25	33.79
40.0	44.72	44.98
50.0	55.83	56.21
60.0	66.97	67.50
70.0	78.08	78.64
80.0	89.15	89.68
90.0	100.46	100.97
100.0	111.56	112.41
110.0	122.76	123.39
120.0	133.93	134.94
130.0	145.07	145.98
140.0	156.16	157.21

<u>TARGET</u>	<u>ACTUAL 25°C</u>	<u>ACTUAL 14°C</u>
20.0g	19.90g	20.16
50.0	50.43g	50.09
75.0	74.98	75.16
90.0	90.05	90.45
115.0	115.16	115.12
140.0	140.34	140.35
350.0	350.95	350.23

Date 13 June 1996
 Date June 13, 1996

Signature Chris Korchinsky
 Witness Paul Korchinsky

STRASTINT 53P STATISTICAL ANALYSIS WITH ORANGE X96Strastint 53P Statistical Analysis

Orange X96

Sample Size n=20 shots

Temperature @ 27.8 C

Strastint Setting	Mean (grams)	3 sigma UCL	3 sigma LCL	\pm % Variation
0.5	0.562	0.597	0.527	6.22
12.0	13.33	13.41	13.33	0.30
12.5	13.93	13.96	13.90	0.22
13.0	14.49	14.54	14.44	0.34
15.0	16.74	16.79	16.68	0.30
25.0	27.85	27.89	27.82	0.14
70.0	78.14	78.18	78.10	0.05
150.0	167.34	167.50	167.18	0.10

Temperature @ 14.0 C

0.5	0.59	0.62	0.55	5.10
12.5	14.01	14.05	13.97	0.29
15.0	16.84	16.91	16.76	0.42
25.0	28.03	28.09	27.96	0.21
70.0	78.60	78.69	78.51	0.11
150.0	168.39	168.50	168.29	0.06

STRASTINT
File STRASTINT.PRE

Date 21 June 1996

Date June 25, 1996


Signature

Witness

John Koch
Jack R. Colechr
June '96

STRASINT 53P STATISTICAL ANALYSIS WITH ORANGE X96

BASED ON THE STATISTICAL ANALYSIS CHART (10120-09), THE % VARIATION IS DRAMATICALLY REDUCED AS VOLUME INCREASES FOR DISPENSING. NEED TO IDENTIFY A LOW END CUTOFF AT = 1-2% VARIATION. THEREFORE, MORE ANALYSIS NEEDS TO BE PERFORMED AT THE LOWER SETTINGS.



Date 21 June 1996
Date June 25, 1996

Signature Chris Koch

Witness Jacqueline Rolen

STRASINT 53P SETTING VS. DELIVERED WEIGHT

AUG. THE 2 EQUATIONS ON 10120-8

$$Y = 0.89422 X - 0.100995$$

Orange X96											
Weight	Settings	Weight	Settings	Weight	Settings	Weight	Settings	Weight	Settings	Weight	Settings
0.56	0.5	39.70	35.5	78.84	70.5	117.98	105.5	157.12	140.5		
1.12	1.0	40.25	36.0	79.40	71.0	118.54	106.0	157.68	141.0		
1.68	1.5	40.82	36.5	79.96	71.5	119.10	106.5	158.24	141.5		
2.24	2.0	41.38	37.0	80.52	72.0	119.66	107.0	158.80	142.0		
2.80	2.5	41.94	37.5	81.08	72.5	120.22	107.5	159.36	142.5		
3.35	3.0	42.50	38.0	81.64	73.0	120.78	108.0	159.92	143.0		
3.91	3.5	43.05	38.5	82.20	73.5	121.34	108.5	160.48	143.5		
4.47	4.0	43.61	39.0	82.75	74.0	121.89	109.0	161.04	144.0		
5.03	4.5	44.17	39.5	83.31	74.5	122.45	109.5	161.59	144.5		
5.59	5.0	44.73	40.0	83.87	75.0	123.01	110.0	162.15	145.0		
6.15	5.5	45.29	40.5	84.43	75.5	123.57	110.5	162.71	145.5		
6.71	6.0	45.85	41.0	84.99	76.0	124.13	111.0	163.27	146.0		
7.27	6.5	46.41	41.5	85.55	76.5	124.69	111.5	163.83	146.5		
7.83	7.0	46.97	42.0	86.11	77.0	125.25	112.0	164.39	147.0		
8.39	7.5	47.53	42.5	86.67	77.5	125.81	112.5	164.95	147.5		
8.95	8.0	48.09	43.0	87.23	78.0	126.37	113.0	165.51	148.0		
9.51	8.5	48.65	43.5	87.79	78.5	126.93	113.5	166.07	148.5		
10.06	9.0	49.21	44.0	88.35	79.0	127.49	114.0	166.63	149.0		
10.62	9.5	49.76	44.5	88.90	79.5	128.05	114.5	167.19	149.5		
11.18	10.0	50.32	45.0	89.46	80.0	128.60	115.0	167.75	150.0		
11.74	10.5	50.88	45.5	90.02	80.5	129.16	115.5	168.30	150.5		
12.30	11.0	51.44	46.0	90.58	81.0	129.72	116.0	168.86	151.0		
12.86	11.5	52.00	46.5	91.14	81.5	130.28	116.5	169.42	151.5		
13.42	12.0	52.56	47.0	91.70	82.0	130.84	117.0	169.98	152.0		
13.98	12.5	53.12	47.5	92.26	82.5	131.40	117.5	170.54	152.5		
14.54	13.0	53.68	48.0	92.82	83.0	131.96	118.0	171.10	153.0		
15.10	13.5	54.24	48.5	93.38	83.5	132.52	118.5	171.66	153.5		
15.66	14.0	54.80	49.0	93.94	84.0	133.08	119.0	172.22	154.0		
16.22	14.5	55.36	49.5	94.50	84.5	133.64	119.5	172.78	154.5		
16.77	15.0	55.92	50.0	95.06	85.0	134.20	120.0	173.34	155.0		
17.33	15.5	56.47	50.5	95.61	85.5	134.76	120.5	173.90	155.5		
17.89	16.0	57.03	51.0	96.17	86.0	135.31	121.0	174.45	156.0		
18.45	16.5	57.59	51.5	96.73	86.5	135.87	121.5	175.01	156.5		
19.01	17.0	58.15	52.0	97.29	87.0	136.43	122.0	175.57	157.0		
19.57	17.5	58.71	52.5	97.85	87.5	136.99	122.5	176.13	157.5		
20.13	18.0	59.27	53.0	98.41	88.0	137.55	123.0	176.69	158.0		
20.69	18.5	59.83	53.5	98.97	88.5	138.11	123.5	177.25	158.5		
21.25	19.0	60.39	54.0	99.53	89.0	138.67	124.0	177.81	159.0		
21.81	19.5	60.95	54.5	100.09	89.5	139.23	124.5	178.37	159.5		
22.37	20.0	61.51	55.0	100.65	90.0	139.79	125.0	178.93	160.0		
22.93	20.5	62.07	55.5	101.21	90.5	140.35	125.5	179.49	160.5		
23.48	21.0	62.62	56.0	101.77	91.0	140.91	126.0	180.05	161.0		
24.04	21.5	63.18	56.5	102.32	91.5	141.46	126.5	180.61	161.5		
24.60	22.0	63.74	57.0	102.88	92.0	142.02	127.0	181.16	162.0		
25.16	22.5	64.30	57.5	103.44	92.5	142.58	127.5	181.72	162.5		
25.72	23.0	64.86	58.0	104.00	93.0	143.14	128.0	182.28	163.0		
26.28	23.5	65.42	58.5	104.56	93.5	143.70	128.5	182.84	163.5		
26.84	24.0	65.98	59.0	105.12	94.0	144.26	129.0	183.40	164.0		
27.40	24.5	66.54	59.5	105.68	94.5	144.82	129.5	183.96	164.5		
27.96	25.0	67.10	60.0	106.24	95.0	145.38	130.0	184.52	165.0		
28.52	25.5	67.66	60.5	106.80	95.5	145.94	130.5	185.08	165.5		
29.08	26.0	68.22	61.0	107.36	96.0	146.50	131.0	185.64	166.0		
29.63	26.5	68.78	61.5	107.92	96.5	147.06	131.5	186.20	166.5		
30.19	27.0	69.33	62.0	108.48	97.0	147.62	132.0	186.76	167.0		
30.75	27.5	69.89	62.5	109.03	97.5	148.17	132.5	187.32	167.5		
31.31	28.0	70.45	63.0	109.59	98.0	148.73	133.0	187.87	168.0		
31.87	28.5	71.01	63.5	110.15	98.5	149.29	133.5	188.43	168.5		
32.43	29.0	71.57	64.0	110.71	99.0	149.85	134.0	188.99	169.0		
32.99	29.5	72.13	64.5	111.27	99.5	150.41	134.5	189.55	169.5		
33.55	30.0	72.69	65.0	111.83	100.0	150.97	135.0	190.11	170.0		
34.11	30.5	73.25	65.5	112.39	100.5	151.53	135.5	190.67	170.5		
34.67	31.0	73.81	66.0	112.95	101.0	152.09	136.0	191.23	171.0		
35.23	31.5	74.37	66.5	113.51	101.5	152.65	136.5	191.79	171.5		
35.79	32.0	74.93	67.0	114.07	102.0	153.21	137.0	192.35	172.0		
36.34	32.5	75.49	67.5	114.63	102.5	153.77	137.5	192.91	172.5		
36.90	33.0	76.04	68.0	115.18	103.0	154.33	138.0	193.47	173.0		
37.46	33.5	76.60	68.5	115.74	103.5	154.88	138.5	194.03	173.5		
38.02	34.0	77.16	69.0	116.30	104.0	155.44	139.0	194.58	174.0		
38.58	34.5	77.72	69.5	116.86	104.5	156.00	139.5	195.14	174.5		
39.14	35.0	78.28	70.0	117.42	105.0	156.56	140.0	195.70	175.0		

Chris Kozhanyan

Date: 21 June 1996
June 25, 1996Signature: Witness: 

10120-12


MANUAL DISPENSE SYSTEM PROTOTYPE

OBJECTIVE: PUT TOGETHER A REACTANT MANUAL DISPENSE SYSTEM UTILIZING THE STRASTINT 53P DISPENSER.


CONNECT THE STRASTINT 53P TO A 5 GALLON PAIL.

PAIL IS A 5 GALLON BLACK 70mm WITH A DELCAN PLUS W/ CLOSURE
- SAMPLE PAIL SUPPLIED BY SMITH CONTAINER.

OVERHEAD VIEW



THE STRASTINT 53P IS MOUNTED TO A ^{CJK} DIFFERENT CLOSURE THAN ONE SUPPLIED WITH PAIL.



Date 25 June 1996

July 22, 1996


Signature

Witness

Chris Konkanis
Janet Rohr


MANUAL DISPENSE SYSTEM PROTOTYPE

CLOSURE CAP 10120-12:



FITTING IS MACHINED TO
FIT IN $3\frac{1}{4}$ " KNOCK-OUT ON ONE
END AND STRAIGHT ON OTHER END

THIS IS THEN SCREWED ONTO CLOSURE OF PAIL.



Date 25 June 1996

Date July 22, 1996

Signature

Witness

Chris Kosher
Jarl Dohle

STRASTINT 53P STATISTICAL ANALYSIS

DETERMINE % VARIATION CURVE AS SETTING IS INCREASED ON
THE STRASTINT 53P DISPENSER.

Strastint 53P Statistical Analysis

Orange X96

Sample Size n=20 shots

Temperature @ 27.8 C				
Strastint Setting	Mean (grams)	3 sigma UCL	3 sigma LCL	± % Variation
0.5	0.562	0.597	0.527	6.22
1.0	1.12	1.15	1.10	2.23
1.5	1.69	1.72	1.66	1.78
2.0	2.24	2.26	2.22	0.89
2.5	2.81	2.83	2.78	0.71
3.0	3.38	3.40	3.36	0.59
12.0	13.37	13.41	13.33	0.30
12.5	13.93	13.96	13.90	0.22
13.0	14.49	14.54	14.44	0.34
15.0	16.74	16.79	16.68	0.30
25.0	27.85	27.89	27.82	0.14
70.0	78.14	78.18	78.10	0.05
150.0	167.34	167.50	167.18	0.10
Temperature @ 14.0 C				
0.5	0.59	0.62	0.55	5.10
12.5	14.01	14.05	13.97	0.29
15.0	16.84	16.91	16.76	0.42
25.0	28.03	28.09	27.96	0.21
70.0	78.60	78.69	78.51	0.11
150.0	168.39	168.50	168.29	0.06

Chris
Kochan
25 Jr. 1996


Date 25 June 1996
Date July 22, 1996

Signature Chris Kochan
Witness Jake Sula

STRASTINT 53P STATISTICAL ANALYSIS

FROM THE CHART ON P10120-14, THE RECOMMENDATION BASED ON THE STATISTICAL DATA IS THAT THE STRASTINT SETTING SHOULD BE SET AT A MINIMUM OF 2.0 TO GET A % VARIATION OF LESS THAN $\pm 1.0\%$. THIS IN TURN EQUATES TO A MEAN OF 2.24 grams MINIMUM DELIVERY.

THE CUSTOMER RECOMMENDATION IS A MINIMUM SETTING OF 2.0 ON THE STRASTINT DISPENSER.



Date 25 June 1996
Date July 22, 1996

Signature Chris Kahanec
Witness Jack Weller

SPECIFIC GRAVITY OF PURPLE X 22

OBJECTIVE: COMPARE SPECIFIC GRAVITY DV-VI-32 TO SPECIFIC GRAVITY CUP.

DATA FROM NIP FORM E - REACTANT PURPLE X 22

<u>TEMP</u>	<u>S.G.</u>	
30°F	1.197	NOTEBOOK REF 10107-25
60°F	1.190	
90°F	1.186	
120°F	1.184	

$$\left\{ R^2 = 0.93620 \right.$$

$$\left. \begin{array}{l} Y = -0.000258x + 1.1954 \end{array} \right.$$

DATA FROM SPECIFIC GRAVITY CUP

<u>TEMP</u>	<u>WEIGHT G</u>	<u>FACTOR X 0.0122</u>	<u>S.G.</u>
25.3°C	99.51g		1.196
33.0°C	99.06g		1.191
39.1°C	98.72g		1.1866
51.9°C	97.95g		1.177
45.0°C	98.27g		1.181

$$\left\{ R^2 = 0.99613 \right.$$

$$\left. \begin{array}{l} Y = -0.000718x + 1.2143 \end{array} \right.$$

BASED ON R^2 LINEARITY - THE SPECIFIC GRAVITY CUP APPEARS TO BE MORE ACCURATE THAN DV-VI-32.

Date 9 July 1996

Date July 22, 1996

Signature Chris Kochan

Witness Jahil Bohan

SPECIFIC GRAVITY CURVE OF REACTNT BLACK X77

- REACTNT BLACK X77 LOT E1004
- GARCO SPECIFIC GRAVITY CUP

OBJECTIVE \Rightarrow DETERMINE SPECIFIC GRAVITY CURVE OF X77 USING
GARCO CUP

<u>TEMP</u>	<u>WEIGHT</u>	$(\times 0.01202)$	<u>S.G.</u>
24.0 °C	93.19 g		1.1201
30.9 °C	92.87 g		1.1163
42.7 °C	92.29 g		1.1093
49.8 °C	91.87 g		1.1043
61.7 °C	91.27 g		1.0971


AI PLOT OF TEMP VS. VISCOSITY YIELDS A
STRAIGHT LINE WITH THE FOLLOWING
EQUATION:

$$Y = -0.000615X + 1.1351$$

$$R^2 = 0.99950$$

Y IS S.G.

X IS TEMP IN °C



Date: 29 July 1996
Date: September 4, 1996

Signature: Chris Korpanoj
Witness: Bill Treskin


OPTIMUM UV STABILIZER PACKAGE FOR RIM

OBJECTIVE : TO PARTICIPATE IN THE STEERING WHEEL MARKET, IT MAY BE NECESSARY TO INCORPORATE A UV STABILIZER PACKAGE IN WITH OUR COLORS (OR SPECIFY TO OUR CUSTOMERS) AS IS CURRENTLY DONE BY PIGMENT COMPETITORS FOR NON-BLACK STEERING WHEELS. MUST DETERMINE WHICH PACKAGE OFFERS THE GREATEST PROTECTION WHILE BEING COMPATIBLE WITH OUR COLORANTS.

GENERAL PREPARATION FOR LIGHTFASTNESS SAMPLES.

A 30.0g OTTOBOCK SAMPLE WILL BE PREPARED IN THE 30g MOLD. MAKE SURE MOLD RELEASE IS USED.

WEIGH CORRECT AMOUNT OF COLOR X phf THEN ADD 30g POLYOL (OTTOBOCK B-SIDE) - MIX THOROUGHLY THEN ADD THE MDI (A-SIDE) AND MIX ON MIXER. POUR INTO MOLD AND LET CURE 10-15 MINUTES BEFORE EXTRACTING FROM MOLD.




Date 8 August 1996
Date September 4, 1996

Signature Chin Koph
Witness Bill Hopkins

UV STABILIZERS FROM CIBA

CONTACT : JOHN O'KEEFE
TECH. SALES REP.
(914) 785-4425 / 2000

CIBA - ADDITIVES DIVISION



Date 8 August 1996

Date September 4, 1996


Signature Chris Koopman

Witness Bill Hawkins

GM STEERING WHEEL SHADE MATCH

$$\begin{array}{l} \text{YELLOW X15 } 34.0\% \Rightarrow 3.40g \\ \text{VIOLET X80LT } 17.5\% \Rightarrow 1.75g \\ \text{RED X64 } 48.5\% \Rightarrow \underline{\underline{4.85g}} \\ \qquad\qquad\qquad 10.0g \end{array}$$

FORMULATION FROM NOTEBOOK 10014-3



Date 8 August 1996

Signature Chin Kyoh

Date September 9, 1996

Witness Bill Tappins

LIGHTFASTNESS TESTING ON UV STABILIZERS FOR A/B SYSTEMS

A 20.0 g COLOR SAMPLE WAS PREPARED USING THE FORMULATION
ON 10120-20 :

YELLOW X15	6.7986g	33.79%
VIOLET X90CT	3.5040g	17.42%
RED X64	9.8168g	48.79%
	<u>20.1194g</u>	

THE FOLLOWING SAMPLES OF UV ABSORBERS, STABILIZERS, ANTI-OXIDANTS
WERE USED IN PREPARING THE 30.0 g A/B SAMPLE.

GENERALLY, UV STABILIZERS ARE IN PACKAGES(IE SEVERAL
UV ABSORBERS ETC.) THE IDEA IS TO TEST EACH INDIVIDUALLY
TO SEE WHICH ONE(S) HAVE THE BEST IMPACT ON LIGHTFASTNESS.
THEN, COMBINE THOSE TO COMPLEMENT A PACKAGE FOR
TESTING.

<u>COMPONENT</u>	<u>MANUF.</u>	
TINUVIN 213	CIBA	UV LIGHT ABSORBER λ_{max} 342 nm
" 328	"	UV " " FOR PLASTICS & COATINGS
" 571	"	
" 765	"	HINDERED AMINE LIGHT STABILIZER
" P	"	
IRGANOX 345	"	
1010	"	
1520	"	
UVITEX OB	"	
CGA 1135	"	

Date 9 August 1996

Signature Chris Koenig

Date September 4, 1996

Witness Bill Hopkins

LIGHTFASTNESS TESTING ON UV STABILIZERS FOR A/B SYSTEMSSAMPLE PREPARATION

30.0 g OTTOBOCK SAMPLE

Formula

STANDARD : POLYOL OTTOBOCK 30.0 g
 COLOR (10120-21) 0.33 g
 MDI 14.4 g

GENERAL

UV STABILIZER : POLYOL OTTOBOCK 30.0 g
 COLOR (10120-21) 0.33 g ($\frac{1}{\text{pp}} \text{ ph}$) ($\frac{4}{\text{pp}} \text{ ph}$)
 UV STABILIZER 0.15 g
 MDI 14.4 g

SAMPLES OF EACH WERE MADE TO SCREEN FOR THE MOST EFFECTIVE STABILIZER :

- SAMPLE # 1) TINUVIN 213 }
 2) " 328
 3) " 571
 4) " 765
 5) " P } THE AMOUNT OF EACH IN
 6) IRGANOX 245 } THE FORMULATION WAS 0.15 g
 7) " 1010
 8) " 1520
 9) UVITEX 08
 10) CEA 1135 }

10 SAMPLES AND A STANDARD ARE SUBMITTED FOR LIGHTFASTNESS TESTING.

Date... 10 August 1996

Date... September 4, 1996

Signature... Chris KorpasWitness... Bill Haykin

CUSTOMER

BLEND PREPARE WITH LOW VOLUME DISPENSE SYSTEM

SCALE: SARTORIUS BASIC ID # 00077

SAMPLE # 1 RED 2043 - 200.0g

$$\begin{array}{l} 60.5\% \text{ RED X64} \Rightarrow 121.0\text{g} \\ 39.5\% \text{ ORANGE X96} \Rightarrow 79.0\text{g} \end{array}$$

FROM WEIGHT TO VOLUME TABLES

PUMP SETTINGS:

$$\begin{array}{l} \text{RED X64} \Rightarrow \text{SET } 105.5 \ (121.0\text{g}) \Rightarrow \text{ACTUAL } 119.58\text{g} \Rightarrow 60.3\% \\ \text{ORANGE X96} \Rightarrow \text{SET } 70.5 \ (78.84\text{g}) \Rightarrow \text{ACTUAL } 78.89\text{g} \Rightarrow 39.7\% \\ \hline & & 198.47\text{g} \end{array}$$

PASS QC: NO \rightarrow DRANGESAMPLE #2 RED 2042 - 200.0g

$$\begin{array}{l} 44.1\% \text{ X96} \Rightarrow 88.2\text{g} \\ 14.8\% \text{ X80LT} \Rightarrow 29.6\text{g} \\ 41.1\% \text{ X64} \Rightarrow 82.2\text{g} \end{array}$$

PUMP SETTINGS:

$$\begin{array}{l} \text{X96} \Rightarrow \text{SET } 79.0 \ (88.35\text{g}) \Rightarrow \text{ACTUAL } 88.39\text{g} \ 44.1\% \\ \text{X80LT} \Rightarrow \text{SET } 27.0 \ (29.75\text{g}) \Rightarrow \text{ACTUAL } 29.88\text{g} \ 14.9\% \\ \text{X64} \Rightarrow \text{SET } 71.5 \ (82.08\text{g}) \Rightarrow \text{ACTUAL } 82.09\text{g} \ 41.0\% \\ \downarrow + 2 \times 0.5 \text{ SHOTS} \\ \hline & & 200.36\text{g} \end{array}$$

PASS QC: YES

Date 26 September 1996
Date October 1, 1996

Signature

Witness

10120-24

CUSTOMER BLENDS PREPARED WITH LOW VOLUME DISPENSE SYSTEM

SCALE SARTORIUS BASIC ID # 00077

REMAKE SAMPLES FROM 10120-23

SAMPLE #1 RED 2043 \Rightarrow POST ADD OF RED X64
RED X64 \Rightarrow SET CTK 0.5ml (0.57g) ACTUAL (0.63g)
ORANGE X96 \Rightarrow SET 9/2L/GC
PASS QC: STILL ORANGE

SAMPLE #1 RED 2043

RED X64 \Rightarrow SET (106.0) (121.69g) ACTUAL (120.08g) + 0.61g = 120.69g
ORANGE X96 \Rightarrow SET
 $\frac{\text{ACTUAL } 78.81g}{199.5g} \times 100\% = 39.5\%$

PASS QC: YES - slight orange shade

Date 26 September 1996
October 1, 1996

Signature

Witness

Chi Kowhom
Jack Miller

10120-25

REMAKE OF CUSTOMER SAMPLE BASED ON % ONLY

DOES % ONLY FORMULATION WORK AS WELL OR BETTER THAN
WEIGHT TO VOLUME TABLES.

REMAKE OF SAMPLE REO 2043 (10120-23, 24)


REX 64 60.5% PUMP SETTING 60.5 LOT DELIVERED 68.52g 60.82%

ORANGE X96 39.5% PUMP SETTING 39.5 WT DELIVERED 44.14g 39.182

112.66g

PASS QC - YES

THIS APPEARED TO BE A BETTER VISUAL MATCH TO
THE STANDARD THAN THE 2043 SAMPLE PREPARED
ON PAGES 10120-23, 24.



Date 36 September 1996
Date October 1, 1996

Signature Chris Korn
Witness Jane Korn

10120-26

CUSTOMER SAMPLE PREPARATION - TAN 2036 PENN FARM

PREPARE SAMPLE WITH LOW VOLUME DISPENSE SYSTEM.

FORMULATION: ORANGE X96: 46.2%

YELLOW X15: 43.6%

VIOLET X80 LT: 10.2%

TOTAL PREPARATION 200.0g

1) PREPARE BY WT TO VOLUME TABLES

$$\begin{array}{lll} X96 \Rightarrow 92.4g \Rightarrow \text{Pump SET } 82.5 & \text{DELIVERED WT: } 92.23g & 46.1\% \\ X15 \Rightarrow 87.2g \Rightarrow \text{Pump SET } 80.0g & & 43.6\% \\ X80LT \Rightarrow 20.4g \Rightarrow \text{Pump SET } 18.5 & & 10.2\% \\ \hline & & 200.13g \end{array}$$

PASS QC: YES

2) PREPARE ONLY BY %


$$\begin{array}{lll} X96 \Rightarrow \text{Pump SET } 92.5 & \text{DELIVERED WT } 103.49g & 47.1\% \\ X15 \Rightarrow \text{Pump SET } 87.0 & & 42.6\% \\ X80LT \Rightarrow \text{Pump SET } 20.5 & & 10.4\% \\ \hline & & 219.95g \end{array}$$


PASS QC: YES

CHOOSE #1 ALTHOUGH EITHER ONE WAS ACCEPTABLE

Date 18 October 1996

Date October 25 1996

Signature 

Witness 

10120-27

CUSTOMER SAMPLE PREP - BROWN 2651

PREPARE 2 SAMPLES AS OR 10120-26

FORMULATION

YELLOW X15 43.8%

ORANGE X96 41.4%

VIOLET X80 14.8%

WT TO VOL. TABLES

1) PREPARE 200.0g

X15 87.6g

X96 82.8g

X80 29.6g

→ PUMP SET 80.5

74.0

27.0

WT

86.63g

82.82g

29.90g

200.56g

+0.54g +0.62g (43.8%)

(41.3%)

(14.9%)

PASS QC : YES

2) PREPARE ONLY BY %

X15 ⇒ PUMP SET 87.6 ⇒ 87.5 WT 94.17g (42.9%)

X96 ⇒ 83.0 92.83g (42.3%)

X80 ⇒ 29.5 32.57g (14.8%)

219.57g

PASS QC : YES

#2 USED FOR CUSTOMER

Date 18 October 1996

Date October 25, 1996

Signature Chris Koenig

Witness Jack Hohen

10120-28


CUSTOMER SAMPLE PREP - GREEN 8218

PREPARE 200.0g SAMPLE FOR CUSTOMER

FORMULATION BLUE X3 LV 82% 164.0g \Rightarrow 162.45g CTK
 YELLOW X15 18% 36.0g \Rightarrow 35.59g 10/22/96

I) X3 \Rightarrow PUMP SET 144.0 \Rightarrow 162.45g \Rightarrow 82.03%
X15 \Rightarrow PUMP SET 33.0 \Rightarrow 35.59g \Rightarrow 17.97%

PASS QC: OK



Date 22 October 1996
October 25, 1996

Signature: Jim Koch [Signature]

Witness: [Signature]

10120-29

CUSTOMER SAMPLE PREP — TAN 2034

PREPARE 1 GALLON SAMPLE FORMULATION WITH MANIFOLD SYSTEM:

FORMULATION: ORANGE X96 60.0% \Rightarrow 2340.0g
YELLOW X15 28.5% \Rightarrow 1111.5g
VIOLEK X80LT 11.5% \Rightarrow 448.5g
 $\sum \frac{3900.0g}{}$

PREPARE 3900.0g SAMPLE

X96 15 SHOTS X PUMP SET 139.5 TO DELIVER 156.00g

1) 156.1g	6) 156.0	11) 156.1
2) 156.0	7) 156.1	12) 156.1
3) 156.0	8) 156.0	13) 156.2
4) 156.1	9) 156.1	14) 156.0
5) 156.1	10) 156.0	15) 156.1
$\sum 780.3$	$\sum 780.2$	$\sum 780.5$

TOTAL = 2341.0g

X15 10 SHOTS X PUMP SET 102.0 TO DELIVER 111.16g

1) 108.7g AIR	6) 109.8	
2) 108.5g AIR	7) 109.8	<u>TOTAL 1095.5g</u>
3) 109.7	8) 109.8	*POST ADD \rightarrow PUMP SET 15.0 \Rightarrow 16.3g
4) 109.8	9) 109.8	
5) 109.8	10) 109.8	<u>TOTAL = 1111.8g</u>
$\sum 546.5$	$\sum 549.0$	

X80LT 3X PUMP SET 135.5 TO DELIVER 149.28g

1) 149.1g	
2) 149.0g	
3) 148.9g	
	<u>TOTAL = 447.0g</u>

PASS QC! YES

FINAL


X96 2341g 60.0%
X15 1111.8g 28.5%
X80 447.0g 11.5%
 $\sum 3899.8g$

Date 25 Oct 1996

October 29, 1996

Signature

Witness



CUSTOMER SAMPLE PREP - GREEN 8218LV

FORMULATION 82% BLUE X3
 18% YELLOW X15
 PREPARE 200g SAMPLE

1) PREPARE BY % ONLY FORMULATION

$$\text{Pumpset: } X3 = 82 \times 2 = 164.0 \\ X15 = 18 \times 2 = 36.0$$

YES - ACCEPTABLE \Rightarrow SAMPLE SHIPPED
 PASS QC: NO ^{10/25/96} - SAMPLE IS ON YELLOW SIDE
 COMPARED TO RETAIN \Rightarrow NEEDS MORE BLUE

2) PREPARE BY WT TO VOLUME TABLES

$$X3: \Rightarrow 164.0 \text{ g} \quad \text{Pumpset 144.0} \Rightarrow 158.97 \text{ g} \Rightarrow (81.7\%) \\ X15: \Rightarrow 36.0 \text{ g} \quad " " 33.0 \Rightarrow \frac{35.62 \text{ g}}{174.59 \text{ g}} \Rightarrow (17.3\%)$$

POST ADD BLUE X3 Pumpset 4.0 \Rightarrow 4.66g

FINAL

X3:	163.63g	(82.1%)
X15:	35.62g	(17.9%)
		<u>199.25g</u>

PASS QC: YES \Rightarrow BETTER MATCH THAN #1

Date 25 October 1996

October 27, 1996

Signature

Chris Kochanek

Witness

Jill Kole

CUSTOMER SAMPLE GREEN 2058

OBJECTIVE: PREPARE 2 $\frac{1}{2}$ GALLONS OF RT BLEND USING
MANUAL LOW VOLUME DISPENSE SYSTEM.

GREEN 2058 FORMULATION

YELLOW X15: 70%

BLUE X3 LV: $\frac{COK}{30\%/\text{gal}} 27\%$

ORANGE X96: 30%

PREPARE FIRST 3900g (1 gal) SAMPLE

YELLOW X15: 2730 g 70%

BLUE X3LV: 1053 g 27%

ORANGE X96: $\frac{117 \text{ g}}{3900 \text{ g}} 3\%$

X15 g (PUMP SETTINGS)

1) 174.7 g (162.5)	11) 10.9 (10)	21) 96.8 g (90)
2) 174.7 g "	12) 10.9 (10)	22) 107.5 " (100)
3) 174.8 "	13) 21.6 (20)	23) 118.3 (110)
4) 180.2 (167.5)	14) 21.6 (20)	24) 129.0 (120)
5) 181.3 (168.5)	15) 32.4 (30)	25) 139.8 (130)
6) 181.7 (169)	16) 43.0 (40)	26) 150.5 (140)
7) 181.8 (169)	17) 53.9 (50)	27) 16.1 (15)
8) 107.6 (100)	18) 64.6 (60)	28) 2.2 (2)
9) 10.2 (10) AIR	19) 75.4 (70)	29) <u>0.7 (0.5)</u>
10) 181.6 (169)	20) <u>86.2 (80)</u>	<u>761.0</u>
	420.5 g	
<u>1548.8 g</u>		

TOTAL YELLOW X15 = 1548.8 + 420.5 + 761.0 = 2730.3g

CONTINUE 10120-32

Date: 1 November 1996
Date: November 26, 1996

Signature: Chris Kohl
Witness: Spirle Mintz

CUSTOMER SAMPLE GREEN J058 - CONT. FROM 10120-31BLUE X3LU g (Pump setting)

1) 11.3 (10)	6) 56.7 (50)	11) 113.1 (100)	16) 6.7 (0.5)
2) 11.3 (10)	7) 67.8 (60)	12) 124.1 (110)	<u>0.7</u> g
3) 22.7 (20)	8) 79.2 (70)	13) 135.5 (120)	
4) 34.0 (20)	9) 90.4 (80)	14) 146.7 (130)	
5) 45.3 (40)	10) 101.7 (90)	15) 12.9 (11.5)	
<u>124.6</u> g	<u>395.8</u> g	<u>532.3</u> g	

$$\text{TOTAL BLUE X3LU} = 124.6 + 395.8 + 532.3 + 0.7 = 1053.4 \text{ g}$$

X96

1) 117.0 g (104.5)

X15: 2730.3 70.6%

X3LU: 1053.4 27.07.

X96: 117.0 3.07.

3900.7 g

PASS QC: YES

BASED ON ABOVE INFO FOR X15 AND X3LU, REPLOT WEIGHT TO VOLUME SETTING TO GET THE CURVE AND EQUATION:

YELLOW X15 EQUATION: $Y = 0.93036 X - 0.08321$
 $R^2 = 0.99999$

$Y = \text{PUMP SETTING}$, $X = \text{X15 WEIGHT}$

BLUE X3LU EQUATION: $Y = 0.88600 X - 0.08169$
 $R^2 = 0.99999$

CONT. 10120-33

WEIGHT TO VOLUME TABLES RECALCULATED BASED ON ABOVE EQUATIONS.

Date 1 November 1996

Signature Chi Kao

Date November 26, 1996

Witness Ashley Mintz

10120-33

CUSTOMER SAMPLE GREEN 2058 - CONT. FROM 10120-32

PREPARE SECOND 3900g (1 GALLON) SAMPLE

X15

1) 151.8 (141)	6) 151.7 (141)	11) 188.3 (175)
2) 10.8 (10.0)	7) 151.8 (141)	12) 188.3 (175)
3) 21.6 (20)	8) 188.3 (175)	13) 94.5 (175 x 5)
4) 107.6 (100)	9) 188.3 (175)	14) 90.4 (84)
5) 161.4 (159)	10) 188.3 (175)	<u>1408.5g</u>
<u>453.2g</u>	<u>868.4g</u>	

$$\text{TOTAL X15} = 2730.1g$$

X3LU

1) 22.6 (20)	6) 612.2 (35.5 x 4)
2) 11.4 (10)	7) 152.6 (135)
3) 34.0 (30)	
4) 84.8 (75)	TOTAL X3LU = 1053.2g
5) 135.6 (120)	

X96

1) 117.0 (104.5)

$$\begin{array}{rcl} \text{X15 : } & 2730.1g & 70.0\% \\ \text{X3LU : } & 1053.2g & 27.0\% \\ \text{X96 : } & 117.0g & 3.0\% \\ \hline & 3900.3g & \end{array}$$

PASS QC : YES

CONT. 10120-34

Date 4 November 1996
Date November 26, 1996

Signature Chin Kochi
Witness Akira Mintz

CUSTOMER SAMPLE - GREEN 2058 - CONT. FROM 10120-33

PREPARE LAST 1950 g (1/2 Gallon)

$$\begin{array}{rcl} X15: & 1365 \text{ g} & 70.0\% \\ X3LU: & 526.5 \text{ g} & 27.0\% \\ X96: & 58.5 \text{ g} & 3.0\% \\ \hline & 1950 \text{ g} & \end{array}$$

$$\begin{array}{rcl} \underline{X15}: & 1) & 1364.3 \text{ g } (158.5 \times 8.5 \text{ shots}) \\ & 2) & \frac{0.7 \text{ g}}{1365.0 \text{ g}} (0.5) \end{array}$$

$$\begin{array}{rcl} \underline{X3LU}: & 1) & 525.6 \text{ g } (93.0 \times 5.5 \text{ shots}) \\ & 2) & \frac{0.8 \text{ g}}{526.4 \text{ g}} (0.5) \end{array}$$

$$\underline{X96}: 1) 58.3 \text{ g } (52.0)$$

$$\begin{array}{rcl} X15: & 1365.0 \text{ g} & 70.0\% \\ X3LU: & 526.4 \text{ g} & 27.0\% \\ X96: & 58.3 \text{ g} & 3.0\% \\ \hline & 1949.7 \text{ g} & \end{array}$$

PASS QC:

Date 4 November 1996
Date November 26, 1996

Signature Chris Koski
Witness Afrika Mintz

CUSTOMER SAMPLE PREP FOR RUBBER LURETHANE

1) FORMULATION - X96 80%
X64 20%


PREPARE 200.0g \Rightarrow X96 160.0g
X64 40.0g

$$\begin{array}{r} \text{X96} & 160.0g \quad (\text{Pumpset } 143.0) \Rightarrow 79.9\% \\ \text{X64} & 40.0g \quad \text{Pumpset } (35.0) + 0.5g \quad \text{Pumpset } (0.5) \quad 20.1\% \\ \hline & 200.0g \end{array}$$

PASS QC: YES

2) 402 SAMPLE OF X96

X96 120.2g (Pumpset 107.5)



Date: November 26, 1996

Date: November 26, 1996

Signature: John Koch

Witness: Shila Mintz

CUSTOMER SAMPLE PREPARATION TAN 2036

OBJECTIVE - PREPARE $\frac{1}{2}$ GALLON OF THE FOLLOWING
FORMULATION: (1950g) MATCH TO RETAIN

$$\begin{array}{l} \text{ORANGE X9L} \quad 46.2\% \Rightarrow 900.9 \text{ g} \\ \text{YELLOW X15} \quad 43.62\% \Rightarrow 850.2 \text{ g} \\ \text{VIOLET X80LT} \quad 10.2\% \Rightarrow 198.9 \text{ g} \\ \hline 1950.0 \text{ g} \end{array}$$

ORANGE X9L WT DELIVERED (PUMP SET)

$$\begin{array}{l} 1) 179.8 \text{ g } (161.0) \text{ AIR} \\ 2) 180.0 \text{ g } (161.0) \\ 3) 180.0 \text{ g } (161.0) \\ 4) 359.9 \text{ g } (161.0) \times 2 \\ 5) 2.2 \text{ g } (2.0) \\ \hline 901.9 \text{ g} \end{array}$$

YELLOW X15

$$\begin{array}{l} 1) 141.4 \text{ g } (132.0) \text{ AIR} \\ 2) 142.0 \text{ g } " \\ 3) 725.8 \text{ g } (132.0) \times 3 \\ 4) 142.0 \text{ g } (132) \\ \hline 851.2 \text{ g} \end{array}$$

"1/3 X9L CTK
ORANGE

VIOLET X80LT

$$\begin{array}{l} 1) 99.4 \text{ g } (90.5) \\ 2) 99.4 \text{ g } " \\ \hline 198.8 \text{ g} \end{array}$$

$$\begin{array}{l} X9L : 901.9 \text{ g } \Rightarrow 46.2\% \\ X15 : 851.2 \text{ g } \Rightarrow 43.6\% \\ X80 : 198.8 \text{ g } \Rightarrow 10.2\% \\ \hline 1951.9 \text{ g} \end{array}$$

PASS QC: NO \Rightarrow NOT VIOLET ENOUGH

CONTINUE: 10120-37

Date: 13 November 1996
Date: November 26, 1996

Signature: Chin Keh
Witness: Sheila Mintz

TAN 2036CONTINUE : 10120-36

X15 POST ADD 1) 1. CTK
 $\frac{0.6g}{1.2g}$ (0.5)

X80LT POST ADD

1) 0.6g (0.5)
 2) $\frac{0.6g}{1.2g}$ (0.5)

⇒ SAMPLE IS VISUALLY MORE ORANGE COMPARED
 TO RETAIN

X15 POST ADD

1) 1.2g (1.0)

SAMPLE IS CLOSE TO RETAIN ⇒ RETAIN IS
 REMADE FOR COMPARISON ⇒ TAN 2036 PASS

FINAL FORMULATION

X 96	901.9g	(46.15%)
X 15	852.4g	(43.62%)
X80LT	200.0g	(10.23%)
<hr/>		
	1954.3g	

Date: 14 November 1996.
 Date: November 26, 1996

Signature: Chin Kali
 Witness: Sheila Mintz

CLEARINT RE DESIGN - QC METHOD FOR CONCENTRATES

OBJECTIVE : DEVELOP A ROBUST QC METHOD FOR CLEARINT CONCENTRATES THAT WILL ACCURATELY MEASURE PRODUCT QUALITY THUS ALLOWING PRODUCT SCALE-UP.

EQUIPMENT : ANALYTICAL BALANCE SARTORIUS ID #000070
METTLER PC 2200 PL ID #00032
KILBON 32:1 EXTRUDER
ARBURG #2 MOLDER

- 1) IDENTIFY PROCESS VARIATION WITH CURRENT QC METHOD FOR CONCENTRATES - CLEARINT SPI - CT SPI 105.R3

PREPARE PLATES WITH QC & BASE RESINS FROM PLASTICS LAB AND CYPRESS & MEASURE DE

- QC RESIN - PLASTICS LAB - FINA 7525 MZ RCP

10MFR PP

RANDOM COPOLYMER

CLARIFIED w/ 2500PPM MILANO 3988

LOT # 17875

} RESIN #1 P

CYPRESS - FINA 7525 - RESIN #1C

CARRIER "BASE" RESIN - PLASTICS LAB EXXON ESCORNE PD 3345-ES

30 MF PP HOMOPOLYMER

STABILIZED, NOT CLARIFIED, PELLETED

LOT 7241213

} RESIN

#2 P

CYPRESS - EXXON PP - RESIN #2C

WEIGH OUT 1000.0g to the nearest pellet in large mixing bowls each of the above resins, 1P, 1C, 2P, 2C

-CONT ON PAGE 10120-39

Date 2 April 1992

Signature

Date April 14, 1997

Witness

John Koenig
Dennis B. Key

-CONT FROM 10120-38

EXTRUDE Each of the 1000.0g sample resins on the Killion 32:1 following extension procedure.

Take extruded samples and mold plaques at 0.04" thickness and measure dE.

<u>RESIN</u>	<u># Plaques</u>	<u>Avg. dE CIELAB</u>	<u>Avg. dE CMc</u>	<u>Dif.</u>
QC - Plastics Lab	20	0.85	0.88	7.79
CYPRESS	16	0.07	0.11	
<u>Base</u> - Plastics Lab	20	0.23	0.11	> 0.07
CYPRESS	20	0.08	0.07	

NEXT - LET DOWNS OF 40:1 & 50:1 of Base resin in QC resin, and measure dE

40:1 \Rightarrow Base resin - 25g both virgin resin
 QC resin - 975g

50:1 \Rightarrow Base resin 20g both virgin resin
 QC resin 980g

<u>RESIN</u>	<u>#Plaques</u>	<u>Avg. dE CIELAB</u>	<u>Avg. dE CMc</u>	
40:1 Plastic Lab	20	0.12	0.11	
CYPRESS	20	0.06	0.07	
50:1 Plastic Lab	10	0.21	0.12	> 0.42
CYPRESS	15	0.08	0.06	

The variation in dE seen by just running the virgin resin through the process is unacceptable especially in 40:1 w/
 the QC resin from the Plastic Lab & Cypress


- CONT. 10120-40

Date 27 April 1997
 Date April 14, 1997

Signature Celia Koenig
 Witness Celia Koenig

-CONT. 10120-39

Rerun new batch of QC resin from Plastics lab when it is received to see if the difference is real.



Date 2 April 1997

Date April 14 1997

Signature

Witness

John Koenig
Lynn B. Koenig

-CONT. 10120-40


Rerun QC resin in Plastics lab with new order resin - still same lot # and do same dE comparison.

QC	RESIN	#	Avg	Aug.	D.F.F.
			dE CIELAB		
	Plastic lab	20	0.08	0.04	> 0.21
	CYPRESS	16	0.07	0.11	

This new batch is much closer in dE to the Cypress QC resin. However, the variation is still unacceptable.

Need to evaluate different resins for less process variation.

IDEA - evaluate styrene based resins.





Date 3 April 1997
Date April 14, 1997


Signature John Koenig
Witness John B. Dey

FINAL - PAIL DOSING SYSTEM DESIGN.



PAIL SWITCHED TO A RECTANGULAR PAIL INSTEAD OF THE ROUND PAIL.



THE PAIL IS SST 1520 (20L)



A NEW CONNECTOR HAD TO BE FABRICATED TO ACCOMMODATE THE NEW PAIL



CONT-10120-43

Date 7 April 1997
Date April 14, 1997



Signature Chi Koch
Witness Agim Ray

-CONT. 10120-42

CONNECTING PUMP TO PAIL

SIDE VIEW

- THREAD PUMP INTO PAIL LID UNTIL GASKET IS SEATED.
- SEAT SPACER FLUSH ON PAIL HANDLE.
- ATTACH CLAMPS ON EACH SIDE OF SPACER.

TOP VIEW

Chris
Kathy
7 April 1997

2010R0CTK

PAGE 3



-cont. 10120-44

Date 7 April 1997
 Date 14 April 1997

Signature Chris Kathy
 Witness Laura B Kay

-CONT. 10120-43

FULLY ASSEMBLED DOSING SYSTEM



Chris
Kohler
7 April 1997

PAGE 6

-CONT. 10120-45

Date 7 April 1997

Date April 14, 1997

Signature


Signature: *Chi K. Lee*

Witness


Signature: *Sgt. B. Kay*

10120-45

-CONT. 10120-44



Chris Kochan 7 April 1997



Chris Kochan 7 April 1997

Date 7 April 1997

Date April 14, 1997

Signature Chris Kochan

Witness Lee Kay

Identify Possible New QC Resin for ClearTint Concentrate

Objective: Determine if there is a better QC resin for ClearTint Concentrate. Currently, Fina 7525 is used as the QC resin for CT concentrate. The base (carrier) resin used in the concentrate has switched from Exxon 3345 to Fina 7620M2. FINA HAS a clarified version Fina 7620M2 that should be evaluated as a QC resin for the concentrate. The qualities for the QC resin must contain the following: highly stabilized, high purity, and lowest but consistent haze values. Also consistent, low yellowness (b value).

FINA 7525M2 2500 ppm Millad LOT 21077 } MOULD 10
 FINA 7620M2 (N97296) 2200 ppm Millad } 50MM PLATEAU

<u>FINA 7525M2</u> CMC			<u>FINA 7620M2</u>		
	<u>HAZE</u>	D b Value		<u>HAZE</u>	b Value
1)	13.4	2.87	0.5005	1)	17.2
2)	13.2	2.85	0.4965	2)	18.0
3)	13.0	2.86	0.5015	3)	17.7
4)	13.0	2.84	0.4990	4)	19.4
5)	12.0	2.83	0.4970	5)	17.9
6)	12.5	2.89	0.5030	6)	19.4
7)	12.9	2.89	0.4995	7)	18.6
8)	12.8	2.85	0.4975	8)	17.7
9)	12.7	2.85	0.4965	9)	18.8
10)	12.8	2.86	0.4976	10)	18.1
<u>X</u>		<u>2.86</u>	<u>0.4988</u>	18.2	2.65
					0.4991


Micrometer - Mitutoyo 15L-101
 BYK Gardner Haze meter ID # 00167
 ACS color computer

Date 25 February 1998
 Date 25 February 1998

Signature: Ghi Koski
 Witness: Beth N Ramsey

CONT FROM PAGE 10120-46

Results: It appears that the Fina 7620 MZ probably won't make a good QC resin due to the haze being higher than the Fina 7528. This effect is due to the different loadings of Millad in these resins.





Date 25 February 1998
Date March 25, 1998

Signature Ch. Koch
Witness Philip Edmonds

BondTint Manifold DesignIDEA
AND

OBJECTIVE: DESIGN A ROBUST BINDER MANIFOLD FOR BONDINT SUCH THAT IT ALLOWS FOR EASY ADDITION OF BONDINT INTO THE BINDER STREAM AND REDUCES OR ELIMINATES THE MANIFOLD PLUGGING DUE TO BINDER BUILD-UP.



3 BONDINT COLORS
+ BLACK
MANIFOLD WILL CONSIST OF 4 PORTS
MANIFOLD INSERT WILL CONSIST OF
TEFLON FABRICATED FROM TEFLO
HOLLOW ROD

QUESTION? - CAN THE INSIDE OF THE S.S. PIPE BE TEFLO
COATED AND DOES THE BINDER SHOW ANY
SIGNS OF STICKING TO THE TEFLO. BINDER/TEFLON
TESTING NEEDS TO BE DONE.

Date 19 October 1998
Date October 19, 1998

Signature *Chikka*
Witness *J. M. D. B.*

10120-49

HAYWARD / BONDINT EXPERIMENT

OBJECTIVE: TRY TO REPRODUCE GELLING THAT WAS
SEEN IN THE BINDER TANK AT HAYWARD.

RAW MATERIALS ARE THOSE BROUGHT BACK FROM
HAYWARD

POLYOL

OIL - CYCLOCUBE 210

BONDINT 1090 - LOT M1115, DRUM #2

RATIO ADDED TO BINDER TANK : 2nd order

		<u>ADD. TIME</u>
TDI	4,640 lbs. 22.7%	32.0 min
Polyol	6,680 lbs. 33.0%	21 min
Color	267 lbs. 1.37%	?
Polyol	6,680 lbs. 33.0% 21 min	
O/I	2,003 lbs 98.99% 22.5 min	
	20,270 lbs	

Sample Prep. 150g

TDI 34.35g → ACTUAL
Polyol 49.5g → ACTUAL
COLOR 1.9g → ACTUAL
POLYOL 49.5g → ACTUAL
O/I ~~150g~~ ^{150g} → ACTUAL
150g

<u>W/O N₂</u>	<u>Temp</u>	<u>W/ N₂</u>	<u>Temp</u>
35.0g	34.3°C	35.0g	25.3°C
49.5g		49.5g	

CONT 10120-50

Date 1 February 1999

Date February 1, 1999

Signature

Chin Kuh


Witness

Jack Mohr


10120-50

CONT. FROM 10120-49

REACTION SET-UP w/o N₂



w/ N₂



CONT. 10120-51

Date 1 February 1998

Date February 10 1998

Signature

Chik

Witness

Jalil

CONT. 10120-50w/ N₂TDI 35.0g
ADD Polyol 49.5g

INITIAL TEMP 25.3°C

10 Minutes 26.1°C

21 Minutes 26.7°C

ADD BT 1.95g

1 minute 28.0

2 minute 29.0

3 minutes 36.0°C

4 Minutes 42.8°C

5 Minutes 44.0

6 Minutes 42.9

No observed viscosity increase w/either

7 Minutes 42.2 °C 42.2 °C

8 Minutes 41.8

9 Minutes 41.3

10 Minutes 40.7

11 Minutes 40.3

12 Minutes 39.7

15 Minutes 38.4

17 Minutes 36.5

ADD Polyol 49.5g

1 minute 38.4

2 minute 36.4

3 minute 37.6

4 minute 38.1

5 minute 39.1

6 minute 39.7

7 minute 40.2

8 minute 40.8

9 minute 40.7

10 minute 40.5

11 min. 40.7

w/o N₂

TDI 35.0g

Polyol 49.5g INITATEP 2432

10 Minutes 25.7°C

21 Minutes 26.4°C

35.6°C

39.9°C

44.0°C

44.6°C

44.0

43.1

42.2 °C

41.6

41.1

40.7

40.1

39.5

38.6

37.8

40.2

43.4

45.5

46.0

45.9

45.6

45.3

44.8

42.9

42.3

41.6

CONT. 10120-52

Date: 1 February 1999
Date: February 1 1999Signature: J. C. Karpick
Witness: J. C. Karpick

CONT 10120-51

	N_2	w/o N_2
12 min	39.8 °C	41.4 °C
13 min	39.5 °C	41.2 °C
14 min	39.2	41.2
15 Min	38.9	41.3
16 min	38.9	41.1
17 Min	38.7	40.8
18 M:z.	38.5	40.5

VISCOOSITY OBSERVED - NO INCREASED VISCOSITY

19 min	38.2	40.3
20 min	37.9	39.9
21 min	36.4	37.4

ADD OIL 14.7g

1 min	33.8	36.2
2 min	35.3	36.1
3 min	38.1	37.0
4 min	38.1	36.6
5 min	37.7	36.2
6 min	37.3	35.8
7 min	37.0	35.6
8 min	36.4	35.2
9 min	36.1	35.0
10 min	35.8	34.7
11 min	35.5	34.4
12 min	35.3	34.2
13 min	35.3	34.2
14 min	35.1	33.9
15 min	35.0	34.7
16 min	34.7	33.3
17 min	34.6	33.2
18 min	34.4	33.1
19 min	34.0	33.0
20 min	33.7	32.7
3 hrs 35 min	23.6	23.0

STARTED HEATING MANTLE - SET POINT 32.2 °C

4 hr 10 min	32.3	35.7
5 hr 36 min	32.3	32.7

CONT - 10120-53

Date 1 February 1999
February 1, 1999Signature *John L. Smith*Witness *J. L. Smith*

10120-53


CONT. 10120-52

N₂
6 hrs 8 min 32.0°C
11:57PM 7 hrs 24 min 32.0

W/o N₂
32.0°C (TOTAL TIME)
32.2°C 7 hr 9 min

NOTE: Observed increased viscosity but still very flexible
7 hrs 55 min 32.3°C 32.1°C TOTAL TIME 8 hr 57 min
12:28AM 2/2/99

Cont. 10120-55



Date 1 February 1999
Date February 1, 1999

Signature JCH/KJW
Witness John K. Wilson

HAYWARD - BT ANALYSIS

OBJECTIVE : DETERMINE ROOT CAUSE FOR BINDER GELLING
AND TANK SET-UP

- RUN TWO REACTIONS - 1) DOUBLE BT AMOUNT
- 2) RUN w/o COLOR

TDI
COP
2/1/99

	<u>BINDER ONLY</u>		<u>2x BT</u>	
TDI	35.0g	- 24.3°C	35.0g	- 23.8°C
ADD Polyol 49.5g	10min	24.5	24.7°C	START APPROX 7:00PM
	21min	24.5	24.5°C	
ADD 4g BT	1 min		35.8	
	2 min		38.8	
	3 min		43.3	
	4 min		43.1	
	5 min		42.5	
	6 min		41.8	
	10 min		39.8	
	15 min		37.8	
	17 min		36.2	
ADD Polyol 49.5g	1mi	24.1	38.5	
	2mi	24.1	42.0	
	3mi	24.1	42.5	
	4mi	24.2	42.0	
heat mantle	15mi	24.6	36.6	
→	45min	32.2°C	32.1°C	
	10:50PM	32.1°C	32.1°C	
	11:58PM	32.1°C	32.1°C	
NOTE: Both are still very flowable				
Feb 2, 1999 12:30 AM	32.2		32.2	

Cont. 10120-55

Date 1 February 1999
Date February 1, 1999

Signature Chi Ki Ho
Witness Jay Dolan

10120-55

CONT. 10120-53, 54

<u>w/ N₂</u>	<u>w/o N₂</u>	<u>BINDER ONLY</u>	<u>2x BT</u>	<u>2x TDI</u>
3/2/99 5:50AM 13 hr 21 min +851 14 hr 22 min	32.2°C 13 hr 21 min 14 hr 22 min	32.2°C	31.8°C	32.4°C
7:20 AM 32.3°C increased viscosity, but flowable	32.2°C increased viscosity, but flowable	31.9 °C slight incr. in viscosity	32.1°C increased viscosity, still flowable	32.1°C increased viscosity, still flowable START 9:33 AM
9:58 AM 31 °C 17 hr 28 min 18 hr 29 min changed temp controller temp up to 44°C	32.0°C	31.9°C	31.7°C	
1:31 PM 33°C ↓ 22 hrs 2 min since start of run	32.5°C	32.3°C 18 hr 33 min since start	32.2	34°C 3 hrs 58 min since start



Date 2 February 1999
 Date 2 February 7, 1999

Signature: *John J. Schaefer*
 Witness: *J. W. Schaefer*

BondTint Manifold Design

-Cont. from 10120-48

Revised idea for BondTint manifold. This incorporates MER's new valve technology into a Stainless Steel 2" ID teflon (FEP) coated interior. The valve ports on this manifold will be located radially on the manifold as opposed to the typical in-line design. The valves are positioned close to one end of the manifold so as to position them as close to the binder pump as possible.



Date 21 April 1999
Date 26 April 1999

Signature


Witness

IDEA — POLYMERIC COLORANTS USED IN
PAINTBALL APPLICATION

THE POPULARITY OF THE GAME OF PAINTBALL CONSUMES
LARGE AMOUNTS OF PAINTBALLS DURING THE GAME.

THE PAINT USED IS NON-STAINING AND SEEMS TO WIPE
OFF OF CLOTHES FAIRLY EASILY.

QUESTIONS! IS THERE A CURRENT POLYMERIC COLORANT
THAT CAN REPLACE THE CURRENT PAINT
USED IN PAINTBALLS? WHAT IS THE
MARKET SIZE?



Date 28 April 1999

Signature Chris K.

Date 17 May 1999

Witness John D. H.


PAINTBALL ANALYSIS

ZAP PAINTBALLS WERE OBTAINED FOR ANALYSIS OF PIGMENT OR DYE COLOR AND TYPE OF CARRIER USED FOR THE PIGMENT / DYE.

MEASURE WEIGHT OF 4 PAINTBALLS.

- 1) 3.2313g
- 2) 3.2460g
- 3) 3.2521g
- 4) 3.2348g

$$\bar{x} = 3.2410g$$



Date 17 May 1999

Date 17 May 1999

Signature

Witness

Chik
J. D. N.Y.A.

ANALYTICAL ANALYSIS OF PAINTBALL CONTENT

Bill Sims
06/09/99 11:59 AM
• • • • •

To: Chris Kochanowicz
cc:
Subject: Yellow Paint

MILLIKEN RESEARCH CORPORATION, ANALYTICAL CHEMISTRY DEPARTMENT

Request No.: 11401
Date Submitted: 05/17/1999
Date Reported: 06/09/1999

Submitted By: Chris Kochanowicz
Location: RMC M-401

Processed By: Bill Sims (M-425, x-2484)

Subject: Yellow Paint

Background and Work Requested:

DETERMINE TYPE OF PIGMENT OR DYE USED AND THE CARRIER FOR THE PIGMENT OR DYE

Samples Evaluated:

1 VIAL CONTAINING YELLOW PAINT

Results and Conclusions:

Analysis of the paint showed the following components:

Carrier - An ethoxylated fatty alcohol or amine (cannot differentiate by FTIR)

Filler - Titanium Dioxide

Dye - Appears to be a polymeric yellow colorant (based on poly EO/PO).
The colorant shows a lambda max at 385 nm in water. This is characteristic of several dyes based on 4-phenylazo aniline.

Chris Kochanowicz June 9, 1999

Date 9 June 1999
Date September 30, 1999


Signature *Chris K.*
Witness *J.W. NAF*

RESPONSE TIME OF COLOR ADDITION (WALL VS. CENTER STREAM)

OBJECTIVE - DETERMINE RESPONSE TIME OF COLOR ADDITION ALONG
WALL VS. CENTER STREAM IN A BINDER
FORMULATION.

BINDER FORMULATION: LAKEWOOD MOI

SET-UP - BONDING TRIAL UNIT WITH DUAL PUMPS
LO FLOW + HIGH FLOW



A TRIAL WAS RUN INTRODUCING COLOR ALONG THE WALL OF THE MANIFOLD AND IN THE CENTER OF THE BINDER STREAM AND THE RESPONSE TIME OF COLOR/BINDER OUTPUT MEASURED. ALSO, BINDER PURGE TIME WAS MEASURED TO WHERE COLOR WAS CLEARED OUT OF THE MANIFOLD USING A BINDER FLUSH.

COLOR CENTER STREAM

COLOR RESPONSE: 17 sec
PURGE TIME: 31 sec

COLOR ALONG WALL

COLOR RESPONSE: 35 sec
PURGE TIME: > 2 min

CONT. 10120-61

Date 10 June 1999

Date September 30, 1999

Signature Chi Kao

Witness Mr. D. Hager


-cont. from 10120-60

Samples collected from the trial where color was introduced center stream & run along the wall were collected in 4oz jars to be studied for gelation over time.

Motor rpm for this trial was 200rpm

$\text{Q } 200 \text{ rpm} \Rightarrow \text{binder flow - } 466.5 \text{ g}$ } from pump
 $\Rightarrow \text{color flow } 11.1 \text{ g}$ } calibration chart

Uncut Blue X3LV with 4% catalyst and cut with
Beadflex bag to a CV of 20 was run through
the manifold



Date 10 June 1999

Date September 30, 1999

Signature Chi Kooh

Witness T. J. + H. S.


SAMPLE UPDATE FROM SAMPLES COLLECTED 10120-61

THE samples collected were purged with N_2 and tightly capped.

The sample collected from the center stream run
~~was caking~~ is still flowable although has high viscosity.

The sample collected where color ran along the wall had completely gelled and was not flowable.

Conclusion: Color introduced in center stream is much more effective means of introducing color into the binder stream. This greatly enhances color response time and drastically reduces purge time. Also, binder stability is much improved by this method of color introduction.



Date 15 June 1999
Date September 30, 1999

Signature Chi Kashi
Witness J.W.H.

10120-63

LQUITONE BLUE 92 LP AS BONDINT

OBJECTIVE: TEST LQUITONE BLUE 92 LP FOR A POSSIBLE
LOW COST BLUE REPLACEMENT FOR BONDINT BLUE 458.

RAW MATERIALS: LQUITONE BLUE 92 LP - STOCK #680500 LOT: P9009
330-LN-L OIL

LQUITONE BLUE 92 LP — COLOR VALUE 52.79
% WATER 21.09%

$$\text{CORRECTED COLOR VALUE } \frac{52.79}{1-0.2109} = 66.90$$

weighed into 500ml round bottom the following:

LQUITONE BLUE 92 LP 84.82g
330-LN-L OIL 156.16g

THIS MIXTURE WAS PUT ON THE ROTOVAPOR UNTIL THE
% WATER WAS LESS THAN 0.5%. FINAL % H₂O
IS 0.02%,

Date 30 September 1999
Date September 30, 1999


Signature Chai Kui
Witness Thy. NAD

BondTint Blue 458 @ CV=17

Objective : Run analysis on BT Blue 458 batch PP005
run in the Pilot Plant at Dewey.

Top Sample: color value: 0.4101g % water: 0.0319g $\frac{0.204}{0.0319} \text{ CT}$ Abs = 0.7003 $\lambda = 620.0$ CV = 17.0%

Bottom Sample: color value: 0.3716g % water: 0.321g Abs. 0.6264 $\lambda = 620.0$ CV = 16.5%



Date 20 November 1999
Date January 5, 2000

Signature Chi R
Witness Daniel Cane

CARBON BLACK PIGMENT DISPERSED IN REACTANT BLACK X77

IDEA: The idea is to disperse carbon black pigment into Reactant Black X77 to produce a stable, super strong black product offering.

RAW Materials: Cabot (Monarch) Black Pearls 1100 CS-3396
 Cabot (Monarch) Black Pearls 820 CS-5669
 RT Black X77 Lot L1703
 Span-80 Lot P5491
 Propylene Carbonate (Acronate HP)

The key to success for this idea is to make a stable, medium to low viscosity product that is at least as strong as the Ferro "Super" Black product. Also, this should give better lightfastness properties than X77 by itself.

The Eiger Mill located in SAB will be used to disperse the carbon black in the X77.

Initial formulation with carbon black

- X77	130.0 g	130.0 g
- Carbon Black (1100)	500.0 g	50.05 g
- Propylene Carbonate	10.0 g	10.12 g
- Span-80	100.0 g	10.03 g
		200.0 g

Formulation has high viscosity.

Date 15 February 2000
 Date April 11, 2000

Signature Chik
 Witness Daniel C

BondTint Blue 458 Viscosity vs. Oil Charge.

IDEA: Is there a viscosity spike in the curve when adding oil to the Blue 458 such that it determines if the emulsion has become homogeneous.

Raw Materials Uncut Blue X3LV Lot V1018 CV = 50.85
 Uncut Violet X80LT Lot B1D10 CV = 24.43
 Bicat V
 Span-80
 350LN-L oil
 $\rightarrow @ CV = 17$

Prepare 300.0 g of BT Blue 458 and add oil at 10% increments and check viscosity on Brookfield Viscometer ID #514.

	<u>Calculated</u>	<u>Actual</u>
Blue X3LV $\Rightarrow \frac{300 \times 17}{50.85} = 100.29$ g	100.32 g	
Violet X80LT $\Rightarrow \frac{300 \times 17}{24.43} * 10\% = 20.88$ g	20.90 g	
SPAN-80 $\Rightarrow 300 \times 10\% = 30.0$ g	30.02 g	
Bicat V $\Rightarrow 300 \times 4\% = 12.0$ g	12.10 g	
OIL $300 - 100.29 - 20.88 - 30 - 12 = 136.86$	136.86	

HEAT 140°F AFTER EACH OIL CHARGE FOR 5 MIN AND MIX

Oil Addition

	<u>Calo.</u>	<u>Act.</u>	<u>Visc. @ 30°C</u>
1st Charge	13.69	13.87	2/16/00

END OF DAY - CONT. 10120-67


Date 16 February 2000
 Date April 11, 2000

Signature John K.
 Witness Daniel L.

- CONT. 10120-66

Oil Addition

	<u>Cal.</u>	<u>Actual</u>	<u>Viscosity @ 30°C</u>
1 st Charge	13.69g	13.87g	3449 cpr
2 nd Charge	13.69g	13.79	2705
3 rd Charge	"	13.76g	2193
4 th charge	"	13.76g	1808
5 th charge	"	14.23g	1484
6 th charge		13.71g	1272
7 th Charge	"	13.78g	1087
8 th charge		13.68g	952.8
9 th charge		13.93g	861.8
10 th charge	"	12.54g	765.8
		<u>136.76 g</u>	

Viscosity of 330-LN-L oil @ 30°C \Rightarrow 86.3 cpr

Date 17 February 2000
 Date April 11, 2000

Signature 
 Witness 

Paintball Analysis

OBJECTIVE: Determine composition of paint in a variety of paintballs.

Paintball color	Color Paint	Paintball Total Weight(g)	Weight of shell	Weight of Paint
	<u>Inside</u>			
1) Yellow	Yellow	3.0274g	0.3339	2.6935g
2) Yellow	"	3.0039g	0.3202	2.6837g
3) Yellow	"	3.0196	0.3283	2.6913g
4) Blue	Pink	3.2187	0.3416	2.8771g
5) Blue	Pink	3.2014		
6) Blue	Pink	3.2134		
7) Green/orange	Orange	3.2752	0.3441	2.9311g
8) Green/orange	Orange	3.2976		
9) Green/orange	Orange	3.2629		
10) Green/white	White	3.2469	0.3037	2.9432g
11) Green/white	White	3.2555		
12) Green/white	White	3.2515		
13) Red	Red	2.9928	0.2915	2.7013g
				19.5212g
				$\bar{x} = 2.7887g$

Date: 22 February 2000
 Date: April 11, 2000

Signature: Chi Koh
 Witness: Daniel James

Low Viscosity Liquitint Analysis with
A peristaltic pump

OBJECTIVE: DETERMINE OUTPUT CONSISTENCY OF LOW
VISCOSITY PRODUCT

- Pink AL/Acid Red 5a Int. 1 cps
- Liquitint Crimson 12 cps
- Masterflex CL Model 77120-60 Peristaltic Pump

Tubing size 0.0449" \Rightarrow 1.869_g \rightarrow 1 min
1.8858_g "

Date 27 March 2000
Date April 11, 2000

Signature Ch. K.
Witness April 11, 2000
Damej Cam

10120-70

REPEAT OF 10120-69

Pink AL/Acid Red 52 Inkt. 1 cps. LOT W1009

Tubing size: 0.0449"

pump setting ~~low~~^{3/10/00} medium

31.5 rpm 1) 1.5546g

2) 1.5592g

3) 1.5426g


4) 1.5640g

5) 1.5508g

51.0 rpm 1) 2.4583g

2) * clumps in bottle - bottle

taken to Jim Stavrikas for analysis



Date 30 March 2000

Date April 11, 2000

Signature

Witness

Ch. K
Daniel Lamm

Repeat of 10120-69 except using
Liquitint Crimson

Liquitint Crimson 12 cps
tubing 0.0449" - ID

20 rpm	1) 0.9899 g 2) 0.9653 g 3) 0.9744 g 4) 0.9599 g 5) 0.9720 g	$\bar{x} = 0.9723$
32 rpm	1) 1.5266 g 2) 1.5296 g	$\bar{x} = 1.5281$
40 rpm	1) 1.8992 g 2) 1.8781 g 3) 1.8970 g	$\bar{x} = 1.8914$
64 rpm	1) 2.9229 g 2) 3.0140 g 3) 2.9503 g	$\bar{x} = 3.0044$

Tubing - 0.0812" ID

22 rpm	1) 3.2909 g 2) 3.2859 g	$\bar{x} = 3.2634$
34 rpm	1) 5.0434 g 2) 5.0127 g	$\bar{x} = 5.0280$
41 rpm	1) 6.0009 g 2) 6.1183 g 3) 6.0403 g	$\bar{x} = 6.0532$
65 rpm	1) 9.4418 g 2) 9.4632 g 3) 9.5631 g	$\bar{x} = 9.4894$

Date 30 March 2000

Date April 11, 2000

Signature

Witness

John R. Conner
Daniel Connor

Test Telura 619 as possible BT diluent replacement

Uncut Blue X3 Lot V1018 CV = 50.85

Uncut Violet X80 Lot B1010 CV = 29.43

SPAN-80 LOT P5491

Bicat V

330-LN-L

Prepare 20g sample of BT Blue 458 using Telura 619 oil as diluent and check for separation.

Formulation

$$X3 \Rightarrow \frac{(20.0\text{ g})(17)}{50.85} = 6.69\text{ g}$$


$$X80 \Rightarrow \frac{(20.0)(17)}{29.43}(10\%) = 1.39\text{ g}$$

$$\text{Span-80} \Rightarrow (20.0)(10\%) = 2.0\text{ g}$$

$$\text{B.Cat V} \Rightarrow (20.0)(4\%) = 0.8\text{ g}$$

$$\text{Oil} \Rightarrow 20 - 6.69 - 1.39 - 2 - 0.8 = 9.12$$

Slide test reveals emulsion and after several hours separation.



Date 6 April 2000

Date April 11, 2000

Signature Jin Kozai

Witness Daniel Cannon

Test Cyclolube 210 same formulation as 10120-72

$$1) X_3 \Rightarrow 6.69 \text{ g}$$

$$2) X_{80} \Rightarrow 1.39 \text{ g}$$


$$3) \text{Span-80} \Rightarrow 2.0 \text{ g}$$

$$4) \text{Bicat V} \Rightarrow 0.8 \text{ g}$$

$$\text{Cyclolube 210} \Rightarrow 9.12 \text{ g}$$

Mix 4 ingredients and heat to 60°C and mix. Then add Cyclolube, heat back to 60°C and mix. Check for separation on slide.

Separation on slide



Date 10 April 2000

Date April 11, 2000

Signature

Witness

GL - L
Daniel Come

10120-72 + Stearic Acid.

Take sample made on 10120-72 and add Stearic acid.


stearic acid 1.7698g

Result: Separation on slide

Add Stearic Acid 6EO to formulation

Result Separation on slide

Note: Material gelled at room temp. but upon re-heating became a liquid.



Date 4 April 2000
Date April 11, 2000

Signature *Gh. Koch*
Witness *Daniel Conn*

BT Blue 458 made with Blue X3 using
Stratcar AmV


- Two samples of uncut Blue X3 using Stratcar AmV
- Test for extraction and stability in BT formulation

uncut Blue X3 Lot D1224 CV = 53.98
 " " Lot PP004 CV = 52.75

Prepare 20g Sample

X3	<u>Lot D1224</u>	6.30g
X80		1.39g
Span-80		2.00g
Bicar V		0.80g
330 LNL		9.51g
		<u>20.00g</u>

LOT	<u>PP004</u>	6.44g
		1.39g
		2.00g
		0.80g
		9.37g
		<u>20.00g</u>



Date 10 April 2000

Date April 11, 2000

Signature Chin K. J.

Witness Daniel Comer